

Installation of the **NAVALOCK® MKIII-A** (part a)



Hold the carrier unit in place.



Slide the holed unit in place.



Fit snugly around the rods.



Use either of the two holes in the carrier unit to place the pin so as to create as snug a fit as is possible,

Installation of the **NAVALOCK® MKIII-A** (part b)



Push the sealing pin all the way into the sealing socket until you hear a distinct click.



Thread the cable seal through one of the available holes in the carrier unit and through the seal clip on the door handle.



Push the sealing pin into the sealing socket until you hear a distinct click.



This completes the installation of the **NAVALOCK® MKIII-A**.